



### Installation Guidelines

#### Securing Wishbone Turisno Waste Receptacle to a concrete pad

#### Concrete Anchor Option

(Dec 2015)

1. Place the waste receptacle in position on the concrete pad.



#### Required Tools and Materials

- ✓ Concrete hammer drill
- ✓ 1/2" concrete drill bit
- ✓ Hammer
- ✓ Air compressor
- ✓ Measuring tape
- ✓ 7/32" allen key
- ✓ Felt marker
- ✓ Paint pen

It is best to have 2 people to install a waste receptacle.

2. Mark with a felt pen where the fasteners need to be positioned, through the bolt hole locations in the base of the receptacle.



3. Remove the waste receptacle from the pad.

4. Set the depth or the drill bit to the length of the anchor using tape on the drill bit.



5. Pre-punch the marked hole locations – this will ensure the drill bit doesn't wander.



6. Drill the holes to a depth of 1-5/8" (as suggested by the anchor manufacturer) – ensure drill is level, straight up and down so that the anchor inserts correctly.



7. Blow out the holes to remove all the concrete dust and debris.



8. Insert concrete anchor. Hammer the anchor with the supplied post tool to expand the anchor's base, securing it to the concrete.



9. Position the waste receptacle on concrete pad, line up holes, and ensure no debris enters the concrete anchors.



10. Another successful installation of Wishbone site furnishings!

