

Perma-Deck

Proper Cleaning

- All exterior products require regular cleaning.
- Use mild soap, diluted bleach (1 cup bleach per bucket of water), and a stiff-bristled brush.
- To rinse, flush with running water.

NEVER use abrasive products or a pressure jet cleaner.

	Perma-Deck Advantage +	Perma-Deck Elegance
Grease stains	Household grease remover	1. Household grease remover 2. For hard-to-remove stains: light sanding/brushing
Mould	Solution: mild soap/bleach	Product containing sodium hypochlorite (bleach)
Leaves, rust	Solution: mild soap/bleach	Product containing oxalic acid or phosphoric acid
Scratches, burns	Light sanding/brushing, stainless steel brush	Light sanding/brushing, stainless steel brush
	Note: Advantage + is not affected by most chemical products. Very easy to maintain.	See the "Deck Cleaners" section of your hardware store or other retail outlet for cleaners that contain these ingredients, and follow the manufacturer's recommendations.